










LED Indicator Reference Index

COLOR	DESCRIPTION	STATUS
	RED/BLUE Alternating	SkyBell battery is charging (10-15 mins)
	YELLOW Solid	SkyBell system start-up mode
	RED/GREEN Alternating	Wi-Fi synchronization mode
	ORANGE Flashing	Wi-Fi not detected, or disconnected
	BLUE/GREEN Alternating	SkyBell connected to Wi-Fi, waiting for SkyBell server connection
	GREEN Solid (or user selected color)	'Ready' mode
	WHITE Solid	'In-Call' mode
	BLUE/YELLOW Alternating	Firmware update in-progress
	BLUE Flashing	Power cycle. HOLD button for 45-seconds. LED will flash to show reset in progress.